


Room Alert[®] 32E/W



**User's Guide &
Reference Manual**

AVT-150401-06

Order at www.sellcom.com/avtech.html 800-SELLCOM

Protect Your Facility...

Don't Wait Until It's Too Late!™



Install Room Alert® Monitors

The Most Advanced, Easy-To-Use, Reliable & Affordable Monitors Available To...

MONITOR, ALERT... LOG, GRAPH... VIEW, REPORT... MANAGE, PROTECT...

- Digital Temperature
- Digital Outdoor Temperature
- Digital Fluid Temperature
- Digital Humidity
- Main / UPS Power
- Flood / Water
- Current Loops (Amperage)
- Extreme Temperature
- Heat Index (Feels Like)
- Smoke / Fire
- Fuel / Water Tank Level
- Air Flow, Sound, Light
- Motion, Room Entry
- Panic Button, Security
- Light Towers, Relay Switches
- Wireless Sensor Hubs
- Network Cameras
- Analog Power & Temp Sensors
- Switch Sensors
- Dry Contacts
- Low Voltage Sensors

**On behalf of the entire team at AVTECH,
we say, “Thank You!” It is our privilege to
serve you, our valued customer.**

Table of Contents

Introduction To Room Alert 32E.....	3
Room Alert 32E/32W Package Contents.....	4
The Room Alert 32E ID Box	4
Front.....	5
Back	6
How To Install Your Room Alert 32E.....	8
Step 1: Connect Your Room Alert 32E Hardware.....	8
If Your Network Is Power Over Ethernet (PoE) Enabled.....	8
If Your Network Is Not Power Over Ethernet (PoE) Enabled.....	8
Step 2: Open And View Your Room Alert 32E In Your Web Browser.....	9
With The Built-In Interface	9
With Device ManageR For Advanced Functionality.....	9
Step 3: Install Additional Components	10
Connect Included External Sensors	10
Connect Other Compatible Components	11
How To Use Room Alert 32E's Web Interface	12
Status.....	12
Current Sensor Status Bar	13
Sensor Display Area	14
Settings.....	15
Network.....	16
SMTP Email.....	19
Simple Network Management Protocol (SNMP)	21
Sensors	24
Alarm Options.....	33
WiSH Sensors	37
WiSH Options.....	41
Security	43

Room Alert 32E

Advanced44

Help.....49

About.....50

Updating & Troubleshooting Your Room Alert 32E51

 How To Download Firmware & Software Updates From AVTECH.com.....51

 How To Update Room Alert 32E’s Firmware.....51

 How To Discover Room Alert 32E When Your Network Blocks UDP Broadcasts52

 How To Reset Room Alert 32E To Factory Defaults.....52

Introduction To AVTECH’s Device ManagerR54



Order from www.sellcom.com/avtech.html
800-SELLCOM 919-401-0067 support@sellcom.com
Protect Your Facility... *Don't Wait Until It's Too Late!*

Introduction To Room Alert 32E

The Room Alert 32E is AVTECH's flagship product that has more of everything to give you the most complete monitoring solution. With the Room Alert 32E, AVTECH brings you *Temperature & Facilities Environment Monitoring... Made Easy*.



In addition to its three (3) internal sensors—one (1) temperature, one (1) humidity and one (1) internal power—the Room Alert 32E has thirty (30) external ports: eight (8) external digital, sixteen (16) external switch, two (2) relay output, two (2) analog input, and two (2) Light Tower & Relay Adapter ports. Our wireless model, the Room Alert 32W, comes in a Room Alert 32E enclosure and has an additional external coaxial port for its antenna.

Install your unit with minimal planning and less hassle.

- ✓ Get up and running in minutes with easy “Plug and Play” setup.
- ✓ Use Power over Ethernet to install even where no DC power is available.
- ✓ Mount Room Alert 32E in a rack, on a wall or ceiling or on a table top.

Get access from anywhere over the web.

- ✓ Configure, monitor and operate Room Alert 32E with its easy-to-use built-in web interface.
- ✓ Significantly expand its functionality with AVTECH's Device Manager, the powerful software bundled FREE with all Room Alert monitors.
- ✓ Have the flexibility to monitor with any SNMP-enabled 3rd-party monitoring application.

Know immediately when physical conditions change.

- ✓ Set alert thresholds for the built-in and bundled external temperature sensor from -40° to 185° F (-40° to 85° C).
- ✓ Set alert thresholds for the built-in humidity sensor from 5% to 95% relative humidity.
- ✓ Monitor the on/off status of the critical power source with the built-in power sensor.
- ✓ Increase your security with the bundled external Room Entry Sensor.
- ✓ Alert multiple contacts on your team when thresholds are exceeded.
- ✓ Receive alert notifications by email, email-to-SMS and more on a computer or mobile phone.

Expand your options as your needs evolve.

- ✓ Extend your reach by adding 7 more external digital sensors up to 100 feet away and 15 more external switch sensors up to 900!
- ✓ Monitor 2 analog sensors using the built-in analog input ports.
- ✓ Automatically turn on/off electrical devices, such as air conditioners or generators, using the 2 built-in relay output ports and/or by adding Relay Switch Sensors (with adapters).
- ✓ Use the 2 Light Tower & Relay Adapter ports to add Light Towers or Relay Switch Sensors.
- ✓ Explore your options further with your AVTECH Product Specialist.

Room Alert 32E/32W Package Contents


The standard Room Alert 32E package includes:

- One (1) Room Alert 32E ID Box
- One (1) Ethernet Cable (10')
- One (1) External Digital Temperature Sensor
- One (1) External Room Entry Switch Sensor
- One (1) Room Alert 32E *User's Guide & Reference Manual* (You're reading it now.)
- One (1) Package Of Literature & Additional Information

The Room Alert 32W (wireless) package includes all of the above, plus:


- One (1) Internal Wireless Assembly & Coaxial Port
- One (1) External Antenna w/13' Cable & Magnetic Mount
- One (1) External Wireless Sensor Hub (WiSH)

The Room Alert 32E ID Box



Front

Power Status LED




An LED indicates the power status to Room Alert 32E.

Green = Main or POE power

Red = Internal UPS power

Ethernet Port




An RJ-45 PoE-enabled port connects Room Alert 32E to your network via an RJ-45 network cable.

Digital Sensor Ports



Eight (8) standard RJ-11 jacks connect any AVTECH digital sensor to your Room Alert 32E via a standard RJ-11 (straight through) telephone cord.

WiSH Signal Strength LEDs (Wireless Model Only)



Three (3) LEDs indicate the signal strength of the last WiSH or WiSPR sensor to communicate with your Room Alert 32W:

- 3 = Strong signal
- 1 = Weak signal

POE, WLAN & GSM LEDs



Three (3) LEDs indicate “in use” status of:

- Built-in PoE
- WLAN (in wireless models)
- GSM (coming in future models)

Room Alert 32E

Digital, Switch & Wireless LEDs



Three (3) LEDs light red or green to indicate alarm or clear status of Digital, Switch or WiSH (wireless model only) sensors:

- **Green** = Clear
- **Red** = Alarm

Light Tower & Relay Adapter Port



A standard RJ-11 jack connects a Light Tower & Relay Adapter to your Room Alert 32E via a standard RJ-11 (straight through) telephone cord.


Back

Relay Output



Two (2) sets of contacts connect any low-voltage device to your Room Alert 32E via standard speaker wire.

Analog Input



Two (2) set of contacts connect any low-voltage analog sensor to your Room Alert 32E via standard speaker wire.

Coaxial Port (Wireless Model Only)



A coaxial jack connects your Room Alert 32W to the included wireless antenna via the antenna's built-in coaxial cable.

Switch Sensors



Sixteen (16) sets of dry contacts connect Room Alert 32E to any AVTECH switch sensor or dry contact on a device (e.g., HVAC, generator, pump, fan, etc.) via standard speaker wire or low-voltage 2-wire cable. Switch Sensor Port 1 is shown here.

Reset Button



A small push button resets Room Alert 32E to factory default settings. (Please push softly.)

On Off Button



A push button turns the Room Alert 32E's internal battery back-up on and off.

Power Port



A standard power port connects Room Alert 32E to an electrical outlet with any AVTECH International Power Adapter.



NOTE

Look for the AVTECH logo. Using another power adapter could damage the Room Alert 32E's circuit board and void the warranty. If you need one, purchase it online sellcom.com AVTECH has an international power adapter with a compatible plug style for each and every country.

How To Install Your Room Alert 32E

Step 1: Connect Your Room Alert 32E Hardware

If Your Network Is Power Over Ethernet (PoE) Enabled

- Connect one end of a standard Ethernet cable to the Room Alert 32E's Ethernet port.
- Connect the other end to a PoE-enabled network jack.



Front

That's it! Your Room Alert 32E is now powered and discoverable on your network.

If Your Network Is Not Power Over Ethernet (PoE) Enabled

A. Connect To Your Network First


- Connect one end of a standard Ethernet cable to the Room Alert 32E's Ethernet port.
- Connect the other end to a network jack.



Front

B. Then Connect To A Power Source

- Plug one end of AVTECH's International Power Adapter into the Room Alert 32E's power port.
- Plug the other end into a surge-protected power source.



Back

Your Room Alert 32E is now powered and discoverable on your network!


NOTE



Use only AVTECH's International Power Adapter. Others could damage the Room Alert 32E and void your warranty.

Step 2: Open And View Your Room Alert 32E In Your Web Browser


With The Built-In Interface



- Enter your Room Alert 32E's IP address in your web browser's address bar to access the interface.

OR

With Device Manager For Advanced Functionality



- Download and install AVTECH's Device Manager via your customer account at AVTECH.com/Downloads.
- Launch it in your web browser at <http://localhost:8080>.

Step 3: Install Additional Components

Connect Included External Sensors


Room Alert 32E and 32W Models

AVTECH's Digital Temperature Sensor and Room Entry Sensor, shown here, come standard with the Room Alert 32E and 32W packages.

Digital Temperature Sensor



Room Entry Sensor



Room Alert 32W Model Only

AVTECH's wireless model, the Room Alert 32W, comes with the external sensors above, plus the External Antenna w/ 13' Cable & Magnetic Mount and a Wireless Sensor Hub (WiSH).

External Antenna w/13' Cable & Magnetic Mount



Wireless Sensor Hub



Please install these items according to the Installation Notes that accompany them.

The Room Alert 32W has a capacity to monitor ten (10) Wireless Sensor Hubs (WiSH) and/or Wireless Sensor Hub & Powered Relays (WiSPR).

Connect Other Compatible Components

If you purchased additional components that are compatible, install them according to the Installation Notes included with them.



Please refer to [Status](#), [Settings](#) and [Alarm Options](#) in this manual for instructions on viewing and configuring your external sensors.

How To Use Room Alert 32E's Web Interface

You may configure your Room Alert 32E through its built-in web interface. To access the interface, you may either:

- Select your Room Alert 32E in Device ManagerR and click the “Open Web” button.
- or
- Type the IP address of your Room Alert 32E monitor directly into the address bar of your web browser.

Your Room Alert 32E's web interface has 4 tabs:

- Status
- Settings
- Help
- About

Status

To view your Room Alert 32E's current sensor status, click **Status** in the navigation bar at the top of your screen.

The screenshot displays the 'Status' page of the Room Alert 32E web interface. The interface has a red header with the title 'Room Alert' and a subtitle 'Advanced Computer Room Environment Monitoring, Alerting & Automatic Corrective Action'. Below the header is a navigation bar with four tabs: 'Status', 'Settings', 'Help', and 'About'. The 'Status' tab is selected. The main content area shows the following information:

- RA32-12345 - Current Sensor Status** 09/08/14 16:07:06 - MAC: XX:XX:XX:XX:XX:XX
- Room Alert® 32E/W vX.X.X**
- Update Every 60 secs**
- Relay Status**
 - Relay Output 1:** Off
 - Relay Output 2:** Off
- Internal Sensors - 2 Installed**
 - Internal 1: Temperature / Humidity**
 - Internal Sensor**
 - Temperature: **75.38 °F** (High: 76.28 °F, Low: 75.20 °F)
 - Humidity: **32.09 %RH** (High: 32.74 %RH, Low: 31.43 %RH)
 - Internal 4: Power**
 - Power Sensor**
 - Power State: **Main Power**
- Digital Sensors - 0 out of 8 Connected**

No Digital Sensors Detected
- Switch Sensors - 16 out of 16 Enabled**

Channel 1: Switch	Channel 2: Switch	Channel 3: Switch	Channel 4: Switch
Switch Sen 1	Switch Sen 2	Switch Sen 3	Switch Sen 4
Circuit State: Open	Circuit State: Open	Circuit State: Open	Circuit State: Open
Channel 5: Switch	Channel 6: Switch	Channel 7: Switch	Channel 8: Switch

Current Sensor Status Bar

Below the Status tab is the “Current Sensor Status Bar,” where you may view basic information about your Room Alert 32E and make temporary adjustments to the sensor display.

- You may find your Room Alert 32E’s name, current date & time, and MAC address here.

RA32-12345	Current Sensor Status	09/08/14 17:48:51	MAC: 00:20:4A:D6:DF:A9	Room Alert® 32E/W vX.X.X
Update Every <input type="text" value="60"/> secs				Fahrenheit <input checked="" type="radio"/> Celsius <input type="radio"/>

- To determine if your Room Alert 32E’s firmware is current, you may click **Room Alert 32E vX.X.X** at the right.

RA32-12345 - Current Sensor Status	09/08/14 17:48:51	- MAC: 00:20:4A:D6:DF:A9	Room Alert® 32E/W vX.X.X
Update Every <input type="text" value="60"/> secs			Fahrenheit <input checked="" type="radio"/> Celsius <input type="radio"/>

TIP



Your Room Alert 32E must be connected to the internet to check firmware versions.

- To temporarily modify the refresh interval of the “Status” screen while viewing, which is 60 seconds (i.e., every 1 minute) by default, you may enter a value in seconds in the “Update Every” field. Click outside the field to temporarily commit the change.

RA32-12345 - Current Sensor Status	09/08/14 17:48:51	- MAC: 00:20:4A:D6:DF:A9	Room Alert® 32E/W vX.X.X
Update Every <input type="text" value="60"/> secs			Fahrenheit <input checked="" type="radio"/> Celsius <input type="radio"/>

- To temporarily toggle the temperature scale between Fahrenheit (F) and Celsius (C), click **Fahrenheit** or **Celsius**.


RA32-12345 - Current Sensor Status	09/08/14 17:48:51	- MAC: 00:20:4A:D6:DF:A9	Room Alert® 32E/W vX.X.X
Update Every <input type="text" value="60"/> secs			Fahrenheit <input checked="" type="radio"/> Celsius <input type="radio"/>

NOTE



Refer to the [Advanced](#) section in this manual for instructions on setting the default status page refresh rate and temperature scale for Room Alert 32E.

Sensor Display Area



In the main viewing pane of the Status tab is the “Sensor Display Area.” Here you may view the current readings for your sensors, which are displayed in a grid on the screen as follows.




Relay Output (2) <i>When enabled in Settings:</i> Light Tower or Relay Switch (2)	Internal Sensors
	Temp & Humidity (1); Analog Input (2) <i>when enabled in Settings</i> ; Power (1)
	Digital Sensors (8)
	Switch Sensors (16)
	Wireless Sensors <i>Room Alert 32W only</i>



Sensors connected to the Analog Input ports and Light Tower/Relay Switch ports do not appear in Status until you enable them in the Settings screen. Refer to [Settings](#) in this manual for instructions.

With each sensor are displayed the status icons and labels, which you may configure in **Settings** → **Sensors**.

Status Icons

-  Green circle with “✓” mark..... Sensor is in a clear state.
-  Grey circle..... Sensor has no alarm threshold set.
-  Red circle with “X” mark..... Sensor is in an alarm state.

Settings

To access your Room Alert 32E’s settings, click **Settings** in the navigation bar at the top of your screen.

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX Version: X.X.X			
<div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Network</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">SMTP Email</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">SNMP</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Sensors</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Alarm Options</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">WISH Sensors</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">WISH Options</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Security</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Advanced</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Save Settings</div> <div style="background-color: #f2f2f2; padding: 5px; margin-bottom: 5px;">Reset Defaults</div>	<h3 style="text-align: center; border-bottom: 2px solid red; margin-bottom: 10px;">Network Settings</h3> <div> Device Name <input style="width: 100px;" type="text" value="RA32-12345"/> </div> <div> IP Address Configuration <div style="margin-left: 20px;"> <input checked="" type="radio"/> Obtain IP Address Automatically </div> <div style="margin-left: 20px;"> Auto Configuration Methods <div style="margin-left: 20px;"> BOOTP <input checked="" type="radio"/> Enable <input type="radio"/> Disable </div> <div style="margin-left: 20px;"> DHCP <input checked="" type="radio"/> Enable <input type="radio"/> Disable </div> <div style="margin-left: 20px;"> AutoIP <input checked="" type="radio"/> Enable <input type="radio"/> Disable </div> </div> <div style="margin-left: 20px;"> <input type="radio"/> Use The Following IP Configuration <div style="margin-left: 20px;"> IP Address <input style="width: 100px;" type="text"/> </div> <div style="margin-left: 20px;"> Subnet Mask <input style="width: 100px;" type="text"/> </div> <div style="margin-left: 20px;"> Default Gateway <input style="width: 100px;" type="text"/> </div> <div style="margin-left: 20px;"> DNS Server IP <input style="width: 100px;" type="text"/> </div> </div> <hr style="border: 0; border-top: 1px solid #ccc; margin: 10px 0;"/> <div> Ethernet Configuration <div style="margin-left: 20px;"> MTU Size <input style="width: 50px;" type="text" value="1024"/> </div> <div style="margin-left: 20px;"> Auto Negotiate <input checked="" type="checkbox"/> </div> <div style="margin-left: 20px;"> Speed <input checked="" type="radio"/> 100 Mbps <input type="radio"/> 10 Mbps </div> <div style="margin-left: 20px;"> Duplex <input checked="" type="radio"/> Full <input type="radio"/> Half </div> <div style="margin-left: 20px;"> Gratuitous ARP Broadcast <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled </div> </div> <div style="text-align: right; margin-top: 10px;"> <input type="button" value="Accept Changes"/> </div> </div>		

TIP




You'll see a prompt for your username and password whenever you click **Settings**. If you have not set up a password for your Room Alert 32E, simply click **OK** without entering anything.

Room Alert 32E

Network

Navigate to **Settings** → **Network** to open the “Network Settings” screen.

Device Name



Device Name	RA32-12345
-------------	------------


↓

Device Name	Server Rm RA32
-------------	----------------

To rename your Room Alert 32E:

1. Select the automatically-assigned name in “Device Name” and enter a new one of up to 15 alphanumeric characters.
2. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
3. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.


IP Address Configuration—DHCP



<input checked="" type="radio"/> Obtain IP Address Automatically
Auto Configuration Methods
<input checked="" type="checkbox"/> BOOTP
<input checked="" type="checkbox"/> DHCP
<input checked="" type="checkbox"/> AutoIP

To obtain an IP address automatically using DHCP:

1. Select **Obtain IP Address Automatically**.
2. Typically, leave the “BOOTP,” “DHCP,” and “AutoIP” at their default, **Enabled**.
3. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
4. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

IP Address Configuration—Static IP

☒ Use The Following IP Configuration

IP Address

Subnet Mask

Default Gateway

DNS Server IP

To assign a static IP address:


1. Select **Use The Following IP Configuration**.
2. In “IP Address,” enter the new static IP address.
3. In “Subnet Mask,” enter the subnet mask.
4. In “Default Gateway,” enter the gateway IP address.
5. In “DNS Server IP,” enter the DNS server IP address.
6. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
7. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.



Make sure that you do not use an IP address that is already assigned to another device. Also, set the IP address within your current subnet range; otherwise, you may not be able to discover your Room Alert 32E.

Ethernet Configuration

Typically, you may leave the “Ethernet Configuration” section at the defaults, which are shown below, for immediate use of Room Alert 32E.



The screenshot shows the 'Ethernet Configuration' section of a web interface. It includes the following settings:

- MTU Size:** A text input field containing the value '1024'.
- Auto Negotiate:** A checkbox that is checked.
- Speed:** Two radio buttons; '100 Mbps' is selected, and '10 Mbps' is unselected.
- Duplex:** Two radio buttons; 'Full' is selected, and 'Half' is unselected.
- Gratuitous ARP Broadcasts:** Two radio buttons; 'Enabled' is selected, and 'Disabled' is unselected.

However, if you connect your Room Alert 32E to a managed switch that controls your network traffic, you may need to change these settings:

1. In “MTU Size,” you may leave the default, 1024, or enter a value as low as 512.
2. You may uncheck “Auto Negotiate” and choose:
 - For “Speed,” 100 Mbps or 10 Mbps.
 - For “Duplex,” “Full” or “Half.”
3. In “Gratuitous ARP Broadcasts,” you may leave the default, “Enabled,” or choose “Disabled.”
4. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
5. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

SMTP Email

You may configure your Room Alert 32E to send alerts via email and email-to-SMS.

Navigate to **Settings** → **SMTP Email** to open the “Email Settings” screen.


Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX Version: X.X.X			
Network SMTP Email SNMP Sensors Alarm Options WiSH Sensors WiSH Options Security Advanced Save Settings Reset Defaults	<h3>Email Settings</h3> <div> Email Enabled <input checked="" type="checkbox"/> Email Footer Enabled <input checked="" type="checkbox"/> Use SMS <input type="checkbox"/> Mail Server Port <input type="text" value="25"/> Timeout <input type="text" value="5"/> Mail Server <input type="text" value="mail.yourco.com"/> * Domain Name or IP Return Address (From) <input type="text" value="RoomAlert@YourCo.com"/> Display URL <input type="text" value="http://192.168.2.131"/> </div> <hr/> <div> Authentication (optional) Enable Authentication <input checked="" type="checkbox"/> Username <input type="text" value="RoomAlert@YourCo.com"/> Password <input type="password" value="*****"/> * Max 11 Characters </div> <hr/> <div> Email Recipients (Separated By Comma) Email Addresses <input type="text" value="ITMgr@YourCo.com, 1235551900@ATT.txt.net, FacilitiesDept@YourCo.com"/> </div> <div> <input type="button" value="Send Test Email"/> <input type="button" value="Accept Changes"/> </div>		

1. Check **Email Enabled**.
2. Leave the **Email Footer Enabled** checked to include AVTECH contact information with email messages.
3. Check **Use SMS** to send a shorter email with a reduced character count.
4. In “Mail Server Port,” enter your mail server’s SMTP port. The default is 25, a commonly-used port.
5. In “Timeout,” you may leave the default, 5 seconds, or enter another interval.
6. In the “Mail Server” field, enter the domain name or IP address of your mail server.
7. In the “Return Address (From)” field, enter an email address that resides on your mail server. This is the address alert messages will come from.
8. In “Display URL,” you may leave the default, which is the IP address and port of your

Room Alert 32E, or overwrite it with another IP address.

Authentication (Optional)


9. If your mail server requires SMTP authentication, check **Enable Authentication**.
10. In “Username” and “Password,” enter a valid username and password for your mail server that will facilitate authentication.



Email Recipients (Separated By Comma)

11. In “Email Addresses,” enter the email and email-to-SMS addresses that you’d like to send alerts to. Separate each address with a comma.
 - Email address: ITMgr@YourCo.com
 - Email-to-SMS address: 1235551900@ATT.txt.net
 - Addresses separated by commas: ITMgr@YourCo.com, 1235551900@ATT.txt.net, etc.
12. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
13. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

When your Room Alert reboots, return to the Email Settings screen and click **Send Test Email** to send a test email to the addresses you entered in Email Recipients.



Simple Network Management Protocol (SNMP)

Because your Room Alert 32E is fully SNMP-compliant, you have the option to monitor it with a 3rd-party monitoring application capable of performing SNMP queries. You may configure the Room Alert 32E to send SNMP Traps in response to a change in alarm states to up to three host systems running 3rd-party SNMP monitoring applications.

If you use a 3rd-party SNMP monitoring application:

- Obtain the Room Alert 32E MIB files through your customer account at AVTECH.com/Downloads and load them into your SNMP monitoring application. Otherwise, your application cannot properly translate the data it receives in the SNMP Trap.
- Ensure that your application uses SNMPv1.
- Note that your Room Alert communicates with your SNMP monitoring application using the standard port for the SNMP protocol, 161.

Navigate to **Settings** → **SNMP** to open the “SNMP Settings” screen.

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX Version: X.X.X			
Network SMTP Email SNMP Sensors Alarm Options WISH Sensors WISH Options Security Advanced Save Settings Reset Defaults	<h3>SNMP Settings</h3> <hr/> SNMP Configuration <div> Community Name <input type="text" value="public"/> <input type="checkbox"/> Use 2 digit SNMP </div> <div> Contact (sysContact) <input type="text"/> </div> <div> Location (sysLocation) <input type="text"/> </div> <hr/> SNMP Sending Configuration <div> Trap Send IP 1 <input type="text" value="0.0.0.0"/> </div> <div> Trap Send IP 2 <input type="text" value="0.0.0.0"/> </div> <div> Trap Send IP 3 <input type="text" value="0.0.0.0"/> </div> <div> <input type="button" value="Accept Changes"/> </div>		

SNMP Configuration

SNMP Configuration

Community Name

public

Contact (sysContact)

IT Manager

Location (sysLocation)

Data Center

☐ Use 2 digit SNMP

To begin configuring your Room Alert 32E for SNMP:

1. In “Community Name,” you may leave the default SNMP protocol community name—“public”—or enter a new name.



The community name you assign here must match the one in your 3rd-party SNMP monitoring application.

2. You may leave “Contact (sysContact)” blank or enter a person’s name to specify who is receiving the information.
3. You may leave “Location (sysLocation)” blank or enter the location of your Room Alert 32E monitor.
4. You may click **Use 2 digit SNMP** if you prefer to receive values in 2-digit rather than 4-digit format.



Room Alert 32E sends values to your 3rd-party SNMP monitoring application in 4-digit format by default. 78.55° F, for example, appears as 7855. In 2-digit format, your values are truncated, not rounded to the nearest number. In this example, 78.55 would appear as 78.

5. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
6. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

SNMP Sending Configuration

You may configure your Room Alert 32E to send SNMP Traps in response to a change in alarm state to up to three host systems running 3rd-party SNMP monitoring applications. Each host system you enter in these fields will receive the same SNMP Traps simultaneously.

SNMP Sending Configuration
Trap Send IP 1
Trap Send IP 2
Trap Send IP 3

To configure your Room Alert to send SNMP Traps:

1. In “Trap Send IP 1,” enter the IP address of the host system that runs your 3rd-party SNMP monitoring application.
2. In “Trap Sent IP 2” and “Trap Send IP 3,” you may enter the IP addresses of other host systems that run 3rd-party SNMP monitoring applications, or leave the default, 0.0.0.
3. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
4. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Sensors

You may configure alert thresholds for the internal temperature, external digital, external analog and external switch sensors connected to your Room Alert 32E in this screen. Your Room Alert 32E sends alerts based on these thresholds.



For more information about AVTECH sensors and accessories, please refer to the [Appendix](#) at the back of this manual

Navigate to **Settings** → **Sensors** to open the Sensor Settings screen.

Status	Settings	Help	About																																													
MAC Address: XX-XX-XX-XX-XX-XX	Version: X.X.X																																															
Network SMTP Email SNMP Sensors Alarm Options WiSH Sensors WiSH Options Security Advanced Save Settings Reset Defaults	<h3>Sensor Settings</h3> <hr/> <p>General Alarm Configuration</p> <p>Degrees Within Threshold Before Alarm Is Cleared <input type="text" value="1"/> (between 0.1 and 25.5)</p> <p>Alarm on sensor disconnect <input type="checkbox"/></p> <hr/> <p>Alarm Thresholds</p> <hr/> <p>Internal Sensor Alarm Configuration</p> <p>Sensor Type: Temp/Humidity (Fahrenheit) Use Alarm Profile: Profile 1 ▼</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td>Internal Sensor</td> <td>Temperature(°F)</td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td>Monitor Heat Index <input type="checkbox"/></td> <td>Humidity (%RH)</td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </tbody> </table> <hr/> <p>Sensor 1 Alarm Configuration</p> <p>Sensor Type: Not Connected Use Alarm Profile: Profile 1 ▼</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td>Ext. Sensor 1</td> <td></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> </tbody> </table> <hr/> <p>Sensor 2 Alarm Configuration</p> <p>Sensor Type: Not Connected Use Alarm Profile: Profile 1 ▼</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td>Ext. Sensor 2</td> <td></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> </tbody> </table> <hr/> <p>Sensor 3 Alarm Configuration</p> <p>Sensor Type: Not Connected Use Alarm Profile: Profile 1 ▼</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td>Ext. Sensor 3</td> <td></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> </tbody> </table>			Sensor Label	Alarm On	High	Low	Adjust	Internal Sensor	Temperature(°F)	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	Sensor Label	Alarm On	High	Low	Adjust	Ext. Sensor 1		<input type="text"/>	<input type="text"/>	<input type="text"/>	Sensor Label	Alarm On	High	Low	Adjust	Ext. Sensor 2		<input type="text"/>	<input type="text"/>	<input type="text"/>	Sensor Label	Alarm On	High	Low	Adjust	Ext. Sensor 3		<input type="text"/>	<input type="text"/>	<input type="text"/>
Sensor Label	Alarm On	High	Low	Adjust																																												
Internal Sensor	Temperature(°F)	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																												
Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																												
Sensor Label	Alarm On	High	Low	Adjust																																												
Ext. Sensor 1		<input type="text"/>	<input type="text"/>	<input type="text"/>																																												
Sensor Label	Alarm On	High	Low	Adjust																																												
Ext. Sensor 2		<input type="text"/>	<input type="text"/>	<input type="text"/>																																												
Sensor Label	Alarm On	High	Low	Adjust																																												
Ext. Sensor 3		<input type="text"/>	<input type="text"/>	<input type="text"/>																																												



Notice the “Alarm Profile” drop-down menu next to each sensor. If you have a Light Tower or Relay Switch Sensor connected to your Room Alert via a Light Tower & Relay Adapter, you may configure Alarm Profiles. Please refer to the [Alarm Options](#) section in this manual for further information.

General Alarm Configuration

In “Degrees Within Threshold Before Alarm Is Cleared,” you may leave the default, 1, or enter a value between 0.1 and 25.5.

General Alarm Configuration	
Degrees Within Threshold Before Alarm Is Cleared	<input type="text" value="1"/> (between 0.1 and 25.5)

You may use this feature to adjust how close your digital temperature sensor readings must get to a high or low threshold before their alarms clear. For example, with the default setting here of 1° and a high threshold of 80°, your temperature sensor will alarm when the temperature rises above 80° and clear when it falls below 79°; likewise, with a low threshold of 60°, the sensor will alarm when the temperature falls below 60° and clear when it rises above 61°.

Internal Sensor Alarm Configuration (Internal Temperature & Humidity Sensor)

You may configure alert thresholds for the Internal Temperature & Humidity Sensor in the “Internal Sensor Alarm Configuration” field. The temperature range is -40° to 185° F (-40° to 85° C), and the humidity range is 5% to 95 %RH.

Internal Sensor Alarm Configuration					
Sensor Type:	Temp/Humidity (Fahrenheit)			Use Alarm Profile:	<div> <div>Profile 1</div> <div>▼</div> </div>
<div> <div>Int Temp & Hum</div> <div> Monitor Heat Index <input type="checkbox"/> </div> </div>	Alarm On	High	Low	Adjust	<div>No Alarm</div> <div>Profile 1</div> <div>Profile 2</div> <div>Profile 3</div> <div>Profile 4</div> <div>Profile 5</div>
	Temperature(°F)	78	60	0	
	Humidity (%RH)	70	50	0	

1. In “Sensor Label,” you may leave the default label, “Internal Sensor,” or rename it to something more descriptive, such as “Int Temp & Hum.”
2. The “Alarm On” field is set at the defaults of “Temperature (F)” and “Humidity (%RH).”



Refer to the [Advanced](#) section in this manual for instructions on setting the default temperature scale.

3. Enter values in the “High” and “Low” field to set high and low temperature and humidity thresholds. Your Room Alert will generate alerts in response to these thresholds.
4. Enter a value in the “Adjust” field to calibrate the Internal Temperature & Humidity Sensor if its readings differ from known values at that location.
5. In “Use Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another profile from the drop-down menu.



Configure Alarm Profiles in the Alarm Options screen of your web interface. Refer to the [Alarm Options](#) section in this manual for detailed instructions.

6. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
7. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Sensor 1 – 8 Alarm Configuration (External Digital Sensors)

You may configure alert thresholds for the eight (8) external digital sensors in the “Sensor 1–8 Alarm Configuration” fields.

In the sample screen below, you see the included external Digital Temperature Sensor in Sensor 1 (which corresponds to the 1st digital sensor port). Sensors 2 and 3 are shown in their default state when those digital ports are unused. Sensors 4 through 8 are not shown.

Notice that the web interface detects the type of digital sensor automatically and enters it in “Sensor Type.”

Sensor 1 Alarm Configuration

Sensor Type: Temperature (Fahrenheit) Use Alarm Profile: Profile 1 ▼

Sensor Label	Alarm On	High	Low	Adjust
Ext. Sensor 1	Temperature(°F)	78	60	0

Sensor 2 Alarm Configuration

Sensor Type: Not Connected Use Alarm Profile: Profile 1 ▼

Sensor Label	Alarm On	High	Low	Adjust
Ext. Sensor 2				

Sensor 3 Alarm Configuration

Sensor Type: Not Connected Use Alarm Profile: Profile 1 ▼

Sensor Label	Alarm On	High	Low	Adjust
Ext. Sensor 3				

1. In “Sensor Label,” you may leave the default label, “Sensor 1,” or rename it to something more descriptive, such as “Ext Temperature.”
2. The “Alarm On” fields automatically match the type of sensor you connect. In this example, the “Alarm On” setting is Temperature.
3. Enter values in the “High” and “Low” field to set high and low thresholds. Your Room Alert 32E will generate alerts in response to these thresholds.
4. Enter a value in the “Adjust” field to calibrate your digital sensor if its reading differs from a known value at that location.
5. In “Use Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another Alarm Profile from the drop-down menu.

NOTE



Configure Alarm Profiles in the Alarm Options screen of your web interface. Refer to the [Alarm Options](#) section in this manual for detailed instructions.

6. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
7. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

TIP



The options in these fields vary slightly depending on the type of digital sensor you connect.

Analog Sensor Settings

You may configure your 0-5 VDC analog sensor in these fields. In the example below, we are configuring AVTECH's Current Loop.

Analog Sensor Settings				
Analog Sensor 1 Alarm Configuration				
Sensor Label	High	Low	Adjust	Enabled
Current Loop	6	2	0	<input checked="" type="checkbox"/>
Use Alarm Profile: Profile 1				

Enable <input checked="" type="checkbox"/>	High	Low
Reference	5	0
Scale	10	0
Units	Amp	

TIP



Work from right to left to configure the Analog Sensor.

1. In the set of fields on the right of the screen, click “Enable” to turn on the “Reference,” “Scale” and “Units” fields.
 - In “Reference,” enter values from 5 to 0 that represent the “High” and “Low” points of your analog sensor’s output signal range. In the case of the Current Loop, which outputs a signal of 0-5 VDC, we’ve left the default values.

- In “Scale,” enter the “High” and “Low” points of the scale you want the “Reference” reading to be converted to. In our Current Loop example, we would like to convert 0-5 volts to 0-10 amps, so we’ve replaced the default of 5 in “High” with 10 and left the default of 0 in “Low.”
- In “Units,” enter a 1- to 3-character label for the unit type that your readings will be measured in. If you are measuring amperage, as with the Current Loop, you might enter “A” or “Amp,” for example. Note that this field is merely a label and does not affect any of the calculations.

**TIP**

The “High” and “Low” fields in “Analog Sensor Settings” can hold up to 6 characters total. With the custom scale enabled, you may enter positive and negative whole numbers. With the custom scale disabled, you may enter positive numbers up to 1 decimal place.

2. In the set of four fields to the left of the screen, click “Enabled” to enable the sensor on the Room Alert web interface and Device Manager software.
 - In “High” and “Low,” you may leave the default, 0—which means no alarm is configured—or enter values of up to 6 characters that fall within the “Scale” range from the previous step. In our example, we entered a conversion scale of 0 to 10 (amps) in the previous step for the Current Loop, and we’ve chosen to generate alarms at the high and low thresholds of 6 and 2 (amps). Note that if you decided not to enable the “Reference,” “Scale” and “Units” fields in the previous step, you must enter numbers within the range 0 to 5 (for 0-5 VDC).
 - In “Sensor Label,” you may leave the default, “Analog Sensor 1” or choose something more descriptive, such as “Current Loop” or “Cryogenic Temp.”
3. In “Use Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another Alarm Profile from the drop-down menu.

**NOTE**

If you have a Light Tower or Relay Switch Sensor connected to your Room Alert, you may configure Alarm Profiles. Please refer to the [Alarm Options](#) section in this manual for further information.

Room Alert 32E

4. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
5. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

External Switch Sensor Settings 1–16

You may configure the alert state for the 16 external switch sensors in the “Switch Sensor Settings” fields. Shown below are the default settings.

Switch Sensor Settings					
Sensor 1 Label	Alarm On	Alarm Profile	Sensor 9 Label	Alarm On	Alarm Profile
Switch Sen 1	Closed ▼	Profile 1 ▼	Switch Sen 9	Closed ▼	Profile 1 ▼
Sensor 2 Label	Alarm On	Alarm Profile	Sensor 10 Label	Alarm On	Alarm Profile
Switch Sen 2	Closed ▼	Profile 1 ▼	Switch Sen 10	Closed ▼	Profile 1 ▼
Sensor 3 Label	Alarm On	Alarm Profile	Sensor 11 Label	Alarm On	Alarm Profile
Switch Sen 3	Closed ▼	Profile 1 ▼	Switch Sen 11	Closed ▼	Profile 1 ▼
Sensor 4 Label	Alarm On	Alarm Profile	Sensor 12 Label	Alarm On	Alarm Profile
Switch Sen 4	Closed ▼	Profile 1 ▼	Switch Sen 12	Closed ▼	Profile 1 ▼

Your Room Alert 32E monitors your switch sensors for an “Open” or “Closed” circuit state. Room Alert defaults to alarming on “Closed,” as you can see above; you may, however, need to change that depending on your sensor. AVTECH’s Motion Sensor, for example, is “Open” when it detects movement and “Closed” when it doesn’t; in that case, you’d likely want to configure the sensor to alarm on “Open” or when motion is detected.

The Alarm And Clear State Of Your Switch Sensor

To determine the alarm and clear state of your sensor, you may either refer to its Installation Note or see for yourself by physically connecting your sensor to your Room Alert and then observing what happens to its circuit state in the Status page.

After you connect your sensor and before you configure it in the Settings page, follow these steps:

1. Click the **Status** tab at the top of your screen in the web interface.
2. Scroll down to the Switch Sensors and look at the circuit state of the channel you connected your sensor to. If you connected your sensor to the first switch sensor port on Room Alert, look at Channel 1; if you connected it to the second, look at Channel 2, etc.

Switch Sensors - 16 out of 16 Enabled			
Channel 1: Switch	Channel 2: Switch	Channel 3: Switch	Channel 4: Switch
✖ Switch Sen 1	✔ Switch Sen 2	✔ Switch Sen 3	✔ Switch Sen 4
Circuit State: Closed	Circuit State: Open	Circuit State: Open	Circuit State: Open

- Notice the circuit state of Switch 1. It should show the normal state, which in this case is “Closed.” (Ignore the red color coding for now. We haven’t configured the sensor yet, so it’s still set at the default: alarm on closed.)
- Now put the sensor into an alarm state. To put a Motion Sensor into an alarm state, for example, wave your hand in front of it.
- Look at the circuit state at the same time. You should see it switch to the opposite of normal. In this example, if normal is “Closed,” you see the alarm state as “Open.” (Again, ignore the green color coding for now.)

Circuit State: **Closed**

Circuit State: **Open**

Now that you’ve checked what “Open” and “Closed” mean on your switch sensor, navigate to **Settings** → **Sensors** to configure your options in “Switch Sensor Settings”:

- In “Sensor Label,” you may leave the default, “Switch 1” (2, 3 or 4) or enter something more descriptive, such as “Ext Motion” or “Main Entry.”
- In “Alarm On,” select the alarm state (“Open” or “Closed”), which you determined on the “Status” page. In our example, the alarm state is “Open.”
- In “Use Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another Alarm Profile from the drop-down menu.

NOTE



If you have a Light Tower or Relay Switch Sensor connected to your Room Alert, you may configure Alarm Profiles. Please refer to the [Alarm Options](#) section in this manual for further information.

- Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
- Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.



TIP

For any of the switch sensor sets you leave unused on your Room Alert 32E, choose **Disabled** from the “Alarm On” drop-down menu to avoid confusion or false alerts.

Internal Power Sensor Alarm Configuration

You may configure the power sensor that is built in to the Room Alert 32E here. This internal power sensor triggers on loss of main power and can send a notification while the battery back-up keeps the monitor powered for a short time.

Internal Power Sensor Alarm Configuration		
Sensor Type:		Power
Sensor Label	Alarm On	Alarm Profile
Power Sensor	Alarm On Power Loss <input checked="" type="checkbox"/>	Profile 1 ▼

1. In “Sensor Label,” you may leave the default “Power Sensor” or enter something more descriptive, such as “RA32 Power.”
2. In “Alarm Power On Loss,” you may leave the checkbox filled in if you wish to receive an alert when your 32E loses its main power source. Otherwise, you may uncheck it.
3. In “Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another Alarm Profile from the drop-down menu.
4. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
5. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Advanced Sensor Configuration

You may configure your Room Alert to send an alert if any of the 8 external digital sensors are disconnected from the unit. This checkbox is blank by default.

Advanced Sensor Configuration	
Trigger Alarm If Sensor Is Disconnected?	<input checked="" type="checkbox"/>

1. Check **Trigger Alarm If Sensor Is Disconnected?** if you want to receive an alert if an external digital sensor becomes disconnected. This check box is blank by default.
2. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
3. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Alarm Options

Navigate to **Settings** → **Alarm Options** to open the Alarm Options screen. Here you may configure devices connected through your 2 Light Tower & Relay Adapter ports and your Room Alert 32E's 2 built-in relay output ports.

Status	Settings	Help	About																																																																																										
MAC Address: XX-XX-XX-XX-XX-XX Version: X.X.X																																																																																													
Network SMTP Email SNMP Sensors Alarm Options WiSH Sensors WiSH Options Security Advanced Save Settings Reset Defaults	<h3>Alarm Options</h3> <hr/> <p>Light Tower / Relay 1 Configuration</p> <p>Light Tower / Relay Label <input type="text" value="Light Tower 1"/></p> <p>Connected Light Tower / Relay <input type="text" value="No Light Tower / Relay Connected"/></p> <table border="1"> <thead> <tr> <th></th> <th>Profile 1</th> <th>Profile 2</th> <th>Profile 3</th> <th>Profile 4</th> <th>Profile 5</th> </tr> </thead> <tbody> <tr> <td>Feature On Boot</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> </tr> </tbody> </table> <p>Light Tower / Relay 2 Configuration</p> <p>Light Tower / Relay Label <input type="text" value="Light Tower 2"/></p> <p>Connected Light Tower / Relay <input type="text" value="No Light Tower / Relay Connected"/></p> <table border="1"> <thead> <tr> <th></th> <th>Profile 1</th> <th>Profile 2</th> <th>Profile 3</th> <th>Profile 4</th> <th>Profile 5</th> </tr> </thead> <tbody> <tr> <td>Feature On Boot</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> <td>On Alarm On Clear</td> </tr> </tbody> </table> <p>Relay 1 Action Configuration</p> <p>Sensor Label <input type="text" value="Relay Output 1"/></p> <table border="1"> <thead> <tr> <th></th> <th colspan="2">Profile 1</th> <th colspan="2">Profile 2</th> <th colspan="2">Profile 3</th> <th colspan="2">Profile 4</th> <th colspan="2">Profile 5</th> </tr> </thead> <tbody> <tr> <td>On Boot</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> </tr> <tr> <td>Off</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> </tr> </tbody> </table> <p>Relay 2 Action Configuration</p> <p>Sensor Label <input type="text" value="Relay Output 2"/></p> <table border="1"> <thead> <tr> <th></th> <th colspan="2">Profile 1</th> <th colspan="2">Profile 2</th> <th colspan="2">Profile 3</th> <th colspan="2">Profile 4</th> <th colspan="2">Profile 5</th> </tr> </thead> <tbody> <tr> <td>On Boot</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> <td>On Alarm</td> <td>On Clear</td> </tr> <tr> <td>Off</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> <td>None</td> </tr> </tbody> </table> <p><input type="button" value="Accept Changes"/></p>				Profile 1	Profile 2	Profile 3	Profile 4	Profile 5	Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear		Profile 1	Profile 2	Profile 3	Profile 4	Profile 5	Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear		Profile 1		Profile 2		Profile 3		Profile 4		Profile 5		On Boot	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	Off	None	None	None	None	None	None	None	None	None	None		Profile 1		Profile 2		Profile 3		Profile 4		Profile 5		On Boot	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	Off	None	None	None	None	None	None	None	None	None	None
	Profile 1	Profile 2	Profile 3	Profile 4	Profile 5																																																																																								
Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear																																																																																								
	Profile 1	Profile 2	Profile 3	Profile 4	Profile 5																																																																																								
Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear																																																																																								
	Profile 1		Profile 2		Profile 3		Profile 4		Profile 5																																																																																				
On Boot	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear																																																																																			
Off	None	None	None	None	None	None	None	None	None	None																																																																																			
	Profile 1		Profile 2		Profile 3		Profile 4		Profile 5																																																																																				
On Boot	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear																																																																																			
Off	None	None	None	None	None	None	None	None	None	None																																																																																			

Room Alert 32E

Light Tower/Relay 1 – 2 Configuration

In “Light Tower / Relay Configuration,” you may configure devices connected to your Room Alert 32E via the Light Tower & Relay Adapter.

Light Tower / Relay 1 Configuration
Light Tower / Relay Label
Connected Light Tower / Relay

	Profile 1	Profile 2	Profile 3	Profile 4	Profile 5
Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear

Light Tower / Relay 2 Configuration
Light Tower / Relay Label
Connected Light Tower / Relay

	Profile 1	Profile 2	Profile 3	Profile 4	Profile 5
Feature On Boot	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear	On Alarm On Clear

A Light Tower & Relay Adapter gives you the option to add an AVTECH Light Tower, Light Tower w/Audio or Relay Switch Sensor. You may also connect a low-voltage device directly to the available relay port.

Shown here is a sample configuration:



NOTE



The Light Tower w/Audio in this configuration can be replaced with a standard Light Tower or Relay Switch Sensor. For more information about AVTECH sensors and accessories, please refer to the [Appendix](#) at the back of this manual

In this example, we'll configure a Light Tower w/Audio in "Light Tower / Relay 1."

Light Tower / Relay 1 Configuration

Light Tower / Relay Label

Connected Light Tower / Relay

Feature	On Boot	Profile 1		Profile 2		Profile 3		Profile 4		Profile 5	
		On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear
Red LED	Off ▼	On ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼
Yellow LED	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼
Green LED	Off ▼	Off ▼	On ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼
Audio 1	Off ▼	Off ▼	Off ▼	On ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼
Audio 2	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼
LTA Relay	Off ▼	On ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼	Off ▼

1. In "Light Tower / Relay Label," you may leave the default, "Light Tower 1" or enter your own, such as "Server Rm RYG."
2. In "Connected Light Tower / Relay," select the appropriate option from the choices in the drop-down menu. For this example, we are choosing **Red/Yellow/Green w/Audio** for the Light Tower w/Audio.
3. Once you choose your device, the "Alarm Profiles" grid beneath it expands. Here you may select "On" or "Off" from the drop-down list for each feature of the device.
 - In the "On Boot" column: Select what each feature does response to the Room Alert 32E rebooting. The default is "Off."
 - In the "Profile 1 – 5" columns: Create up to 5 different sets of on/off actions to associate with sensors when they go in and out of an alarm state. The default for each feature is "Off."
4. Above, you see the grid for the Light Tower w/Audio (including the built-in relay port on the Light Tower & Relay Adapter). For our example, we've configured Profile 1 and Profile 2 out of the 5 available profiles.



The alarm options available in the "Feature" column vary depending on the device you select.

Room Alert 32E

Relay 1 – 2 Action Configuration

Here you may set the devices connected through the built-in relay output ports to turn on or off in response to your Room Alert 32E rebooting or its sensors going in and out of alarm state.

In this example, we'll configure Relay 1.

Relay 1 Action Configuration										
Sensor Label <input type="text" value="Server Rm AC"/>										
	Profile 1		Profile 2		Profile 3		Profile 4		Profile 5	
On Boot	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear	On Alarm	On Clear
Off ▾	On ▾	Off ▾	None ▾	None ▾	None ▾	None ▾	None ▾	None ▾	None ▾	None ▾

1. In “Sensor Label,” you may leave the default, “Relay 1,” or enter something more descriptive, such as “Server Rm AC.”
2. In the “On Boot” column, you may select what the relay output does in response to the Room Alert 12E rebooting. The default is “Off.”
3. In the “Profile 1–5” columns, you may create up to 3 different sets of on/off actions to associate with sensors when they go in and out of an alarm state. In this example, we’ve configured Profile 1 and left Profiles 2 through 5 at the default of “None.”

Associate Alarm Profiles With Sensors

Each sensor is set at “Profile 1” by default: the Light Tower, built-in LTA Relay, Relay Switch Sensor and built-in Relay Output execute Profile 1 when that sensor goes into an alarm state. Once you have configured at least 1 more profile, you may associate it with a sensor. When that sensor goes into an alarm state, the features of those devices react by turning on or off.

In our example, we will associate Profile 1 with our external Digital Temperature Sensor and Profile 2 with our external Room Entry sensor.

1. Navigate to **Settings** → **Sensors**.
2. Find your sensor’s interface and choose the profile you’ve configured from the drop-down list in “Use Alarm Profile.” Note that the default for all sensors is Profile 1.

Sensor 1 Alarm Configuration

Sensor Type: Temperature (Fahrenheit) Use Alarm Profile: Profile 1 ▼

Sensor Label	Alarm On	High	Low	Adj
Ext Temperature	Temperature(°F)	78	60	0

Profile 1 is selected in the Use Alarm Profile dropdown menu.

Sensor 1 Label	Alarm On	Alarm Profile
Room Entry	Open	Profile 1
Sensor 2 Label	Alarm On	No Alarm
Switch Sen 2	Closed	Profile 1
Sensor 3 Label	Alarm On	Profile 2
Switch Sen 3	Closed	Profile 3
		Profile 4
		Profile 5

- Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
- Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.



TIP

Alarm Profiles do not affect email alerts.

WiSH Sensors

Navigate to **Settings** → **WiSH Sensors** to access your wireless sensor hubs. A Wireless Sensor Hub (WiSH) is included with Room Alert 32W. AVTECH also offers a Wireless Sensor Hub & Powered Relay (WiSPR). Your web interface automatically detects WiSH and/or WiSPR hubs that are in range. Below you see the WiSH Sensor Settings screen at defaults and detecting a WiSH or WiSPR sensor.

Status	Settings	Help	About																																										
MAC Address: XX-XX-XX-XX-XX-XX		Version: X.X.X																																											
<ul style="list-style-type: none"> Network SMTP Email SNMP Sensors Alarm Options WiSH Sensors WiSH Options Security Advanced 	<h3>WiSH Sensor Settings</h3> <p>WiSH Sensor: WiSH Sensor 1 ▼ Reset This WiSH Sensor</p> <p>Sensor Label: WiSH Sensor 1 Serial: 123456789012</p> <p>Internal Sensor Alarm Configuration Sensor Type: Temperature</p> <table border="1"> <thead> <tr> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td>Temperature (°F)</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <p>External Sensors:</p> <p>Sensor 1 Alarm Configuration Sensor Type: Disconnected</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td></td> <td>Temperature (°F)</td> <td></td> <td></td> <td></td> </tr> <tr> <td>Monitor Heat Index <input type="checkbox"/></td> <td>Humidity (%RH)</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>Sensor 2 Alarm Configuration Sensor Type: Disconnected</p> <table border="1"> <thead> <tr> <th>Sensor Label</th> <th>Alarm On</th> <th>High</th> <th>Low</th> <th>Adjust</th> </tr> </thead> <tbody> <tr> <td></td> <td>Temperature (°F)</td> <td></td> <td></td> <td></td> </tr> <tr> <td>Monitor Heat Index <input type="checkbox"/></td> <td>Humidity (%RH)</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>Switch Sensor Alarm Configuration Sensor Type: Switch</p> <table border="1"> <thead> <tr> <th>Switch Sensor Label</th> <th>Alarm On</th> </tr> </thead> <tbody> <tr> <td>WiSH 1 Switch</td> <td>Closed ▼</td> </tr> </tbody> </table> <p>Alarm Profile: No Profile ▼</p> <p>Accept Changes</p>			Alarm On	High	Low	Adjust	Temperature (°F)	0	0	0	Sensor Label	Alarm On	High	Low	Adjust		Temperature (°F)				Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)				Sensor Label	Alarm On	High	Low	Adjust		Temperature (°F)				Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)				Switch Sensor Label	Alarm On	WiSH 1 Switch	Closed ▼
Alarm On	High	Low	Adjust																																										
Temperature (°F)	0	0	0																																										
Sensor Label	Alarm On	High	Low	Adjust																																									
	Temperature (°F)																																												
Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)																																												
Sensor Label	Alarm On	High	Low	Adjust																																									
	Temperature (°F)																																												
Monitor Heat Index <input type="checkbox"/>	Humidity (%RH)																																												
Switch Sensor Label	Alarm On																																												
WiSH 1 Switch	Closed ▼																																												
<p>Save Settings</p> <p>Reset Defaults</p>																																													

1. In “WiSH Sensor,” choose the discovered WiSH you want to configure from the drop-down list. In this example, we’ve chosen WiSH Sensor 1.
2. In “Sensor Label,” you may leave the default, “WiSH Sensor 1,” or enter something more descriptive, such as “Server Rm WiSH.”
3. In “Serial,” the interface automatically detects and displays the WiSH sensor’s serial number. In this example, WiSH Sensor 1’s serial number is 123456789012
4. Record this number on the label on the bottom of your sensor so you’ll know which physical WiSH corresponds to what you’re seeing in the interface.



Room Alert 32W can support up to 10 WiSH or WiSPR hubs at one time. This adds a capacity of 40 additional sensors. Visit the Sensors section of AVTECH.com to purchase additional WiSH or WiSPR hubs.

AVTECH – WiSH (Power)

Sensor works with **Room Alert 32W and 26W** only.

Do NOT leave powered when not in use.

Serial # 123456789012 vX.X
AVTECH.com * 401.628.1600

5. Only click **Reset This WiSH Sensor** if you wish to clear your current WiSH settings and change them back to the defaults.

Configuring internal, external digital and external switch sensors has been covered in this manual in the [Sensors](#) section; please refer back to that section for instructions on configuring sensors connected to the WiSH, or look specifically at the sub-sections listed below:

Internal Sensor Alarm Configuration

- Please refer to [Internal Sensor Alarm Configuration](#) in this manual for instructions on configuring the WiSH's internal temperature sensor.

External Digital Sensors (Sensors 1 & 2 Alarm Configuration)

- Please refer to [Sensor 1-8 Alarm Configuration](#) in this manual for instructions on configuring the external switch sensor you connect to the WiSH.



Refer to the [Advanced](#) section in this manual for instructions on setting the default temperature scale.

External Switch Sensor Alarm Configuration

- Please refer to [External Switch Sensor Settings 1-16](#) in this manual for instructions on configuring the external switch sensors you connect to the WiSH.

6. In “Alarm Profile,” which controls devices connected through the Light Tower & Relay Adapter Ports, you may leave the default, “Profile 1,” or choose another Alarm Profile from the drop-down menu. The Profile you choose here applies to all sensors connected to the WiSH: its internal, external digital and external switch sensors.



If you have a Light Tower or Relay Switch Sensor connected to your Room Alert via a Light Tower & Relay Adapter, you may configure Alarm Profiles. Please refer to the [Alarm Options](#) section in this manual for further information.

7. Click Accept **Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
8. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Repeat the steps above for each discovered WiSH. A maximum of ten WiSH or WiSPR hubs can be used with each Room Alert 32W monitor.

Please see the next section, WiSH Options, for more configurable WiSH features.

WiSH Options

Navigate to **Settings** → **WiSH Options** to access advanced options and filters for each Wireless Sensor Hub (WiSH) or Wireless Sensor Hub & Powered Relay (WiSPR).

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX	Version: X.X.X		
Network	WiSH Sensor Options		
SMTP Email	Advanced WiSH Sensor Options		
SNMP	Enable WiSH Lost Communication Alarms <input checked="" type="checkbox"/>		
Sensors	WiSH Timeout (10-254) <input type="text" value="10"/> (Number Of Missed WISH Packets)		
Alarm Options	WiSH Sensors Enabled (0-10) <input type="text" value="10"/>		
WiSH Sensors			
WiSH Options			
Security	WiSH Sensor Filter Configuration		
Advanced	Enable WiSH Sensor Filter <input type="checkbox"/>		
	Allowed WiSH Sensors (Select to Block)		
	<div>WiSH Sensor 1 -</div> <div></div>		
	Blocked WiSH Sensors (Select to Allow)		
	<div>No Filtered WiSH Sensors</div> <div></div>		
	<input type="button" value="Reset All WiSH Sensors"/> <input type="button" value="Accept Changes"/>		

Advanced WiSH Sensor Options

1. In “Enable WiSH Lost Communications Alarms,” you may leave the box checked, which is the default, or disable it by unchecking the box.
2. In “WiSH Timeout (10-254),” you may enter the number of packets to allow Room Alert to miss before an alarm is generated. You may enter a value between 10 and 254; the default is 10. This prevents false alerts if the wireless signal is temporarily interrupted.
3. In “WiSH Sensors Enabled (0-10),” you may specify the maximum number of WiSH or WiSPR units you want to monitor. You may leave the default, 10, or enter a lower number.

WiSH Sensor Filter Configuration


In this section, you may block your Room Alert 32W from communicating with some or all of your WiSH sensors. You may need this feature if you want only certain WiSHes recognized.

1. In “Enable WiSH Sensor Filter,” check the box to enable filtering. It is disabled (unchecked) by default.

Room Alert 32E

2. In “Allowed WiSH Sensors,” you see a list of WiSHes recognized by your Room Alert 32W. To block a certain WiSH, perform these steps:

- Click on the WiSH to highlight it.
- Select **Accept Changes** at the bottom of the page to move that WiSH to the “Blocked WiSH Sensors” box.



The image shows a web interface titled "WiSH Sensor Filter Configuration". It has a checkbox labeled "Enable WiSH Sensor Filter" which is checked. Below this are two list boxes: "Allowed WiSH Sensors (Select to Block)" and "Blocked WiSH Sensors (Select to Allow)". The "Allowed" box contains one item, "WiSH Sensor 1 - 4B10DC", which is highlighted in blue. A red arrow points from this item down to the "Blocked" box, which currently contains the text "No Filtered WiSH Sensors". At the bottom of the interface are two buttons: "Reset All WiSH Sensors" and "Accept Changes". The "Accept Changes" button is highlighted with a red rectangular border.

3. Then select **Save Settings** in the navigation bar to the left. Your Room Alert 32W will automatically reboot and commit your changes.

To unblock that WiSH, perform the same steps on it, moving it from the “Blocked WiSH Sensors” box back to the “Allowed WiSH Sensors box.”

Security

By default, the Room Alert 32E does not require log in credentials; you may, however, create a password for your Room Alert 32E for extra security.

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX		Version: X.X.X	
<ul style="list-style-type: none"> Network SMTP Email SNMP Sensors Alarm Options WiSH Sensors WiSH Options Security Advanced Save Settings Reset Defaults 	<h3>Security Settings</h3> <div> Current Password <input type="password"/> New Password <input type="password"/> Confirm Password <input type="password"/> </div> <div>Accept Changes</div>		

Navigate to **Settings** → **Security** to open the “Security Settings” screen.

1. In “Web Password,” you may create a log in password of up to 15 alphanumeric characters for your Room Alert 32E.



TIP

Use only letters and numbers in your log in password—no special characters, please.

2. Re-enter the password in the “Confirm Password” field to verify.
3. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
4. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.



NOTE

If you forget your password, you can reset your Room Alert 32E settings to the factory defaults. Please see the [How To Reset Room Alert 32E To Factory Defaults](#) section of this manual for more information. There is no other alternative.

Advanced

You may configure a number of advanced options here, including Status screen defaults, Device ManageR “Push,” time & date, and trace output.

Navigate to **Settings** → **Advanced** to open the “Advanced Settings” screen.

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX Version: X.X.X			
Network SMTP Email SNMP Sensors Alarm Options WISH Sensors WISH Options Security Advanced Save Settings Reset Defaults	<h3>Advanced Settings</h3> <hr/> <div> Status Page Configuration Refresh Rate (seconds) <input type="text" value="60"/> HTTP Port <input type="text" value="80"/> Temperature Scale <input type="text" value="Fahrenheit"/> </div> <hr/> <div> Device ManageR Push Configuration Enable Device ManageR Push <input type="checkbox"/> Server IP Address <input type="text" value="0.0.0.0"/> Server Port <input type="text" value="8080"/> Push Interval <input type="text" value="1 Minute"/> </div> <hr/> <div> Time & Date Configuration Time Zone <input type="text" value="(GMT) Greenwich Mean Time (London, Lisbon)"/> Time Display <input type="text" value="24 hour"/> Time Format <input type="text" value="MM/DD/YY Hour:Minute:Second"/> Daylight Savings <input type="checkbox"/> Adjust For Daylight Saving Time (+1 hr) Time Server IP <input type="text" value="198.82.1.201"/> Resolve hostname? Time Server Auto Refresh <input type="text" value="24 Hours"/> <input type="button" value="Update Now"/> </div> <hr/> <div> Trace Configuration Enable Tracing <input type="checkbox"/> Trace Port <input type="text" value="143"/> </div> <div style="text-align: center;"> <input type="button" value="Accept Changes"/> </div>		

Status Page Configuration

You may set defaults for the Status screen here.

Status Page Configuration

Refresh Rate (seconds)

HTTP Port

Temperature Scale


1. In “Refresh Rate (seconds),” enter the number of seconds you would like the Status screen to refresh at. You may enter a value from 5 to 65535. The default is 60 seconds (i.e., every 1 minute).
2. In “HTTP Port,” you may change the port number your web browser uses to connect to your Room Alert’s web interface. It uses port 80 by default.
3. In “Temperature Scale,” you may choose “Fahrenheit” or “Celsius” from the drop-down list. “Fahrenheit” is the default.
4. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
5. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Device ManageR Push Configuration

By default, Device ManageR queries your Room Alert 32E for sensor values at defined intervals. However, you may configure your Room Alert 32E to proactively send sensor updates to Device ManageR by enabling “Device ManageR Push.”

Enabling “Device ManageR Push” is an advantage for two reasons:

- Your Room Alert 32E can communicate with Device ManageR without triggering any firewalls between the two. Firewalls typically allow out-going connections while blocking in-coming connections.
- Your Room Alert 32E can immediately send an update to Device ManageR when it detects an alarm, regardless of any intervals you have configured either in this section or in the Device ManageR discovery interval.



Device ManageR Push Configuration

Enable Device ManageR Push ☒

Server IP Address

Server Port

Push Interval

To enable Push to Device ManageR from your Room Alert 32E:


1. Select **Enable Device ManageR Push**.
2. In “Server IP Address,” enter the IP address of Device ManageR’s host system.

Room Alert 32E

3. In “Server Port,” enter the port Device ManageR uses. The default is 8080.
4. In “Push Interval,” choose the number of minutes you would like between pushes from the drop-down list.
5. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
6. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Time & Date Configuration


You may set the time and date defaults for your Room Alert 32E here.



The screenshot shows the 'Time & Date Configuration' web interface. It contains several settings: 'Time Zone' is set to '(GMT) Greenwich Mean Time (London, Lisbon)' with a dropdown arrow; 'Time Display' is set to '24 hour' with a dropdown arrow; 'Time Format' is set to 'MM/DD/YY Hour:Minute:Second' with a dropdown arrow; 'Daylight Savings' is an unchecked checkbox; 'Adjust For Daylight Saving Time (+1 hr)' is a text label; 'Time Server IP' is set to '198.82.1.201' in a text box, with a link 'Resolve hostname?' next to it; 'Time Server Auto Refresh' is set to 'Disabled' with a dropdown arrow; and an 'Update Now' button is at the bottom right.

1. In “Time Zone,” select your time zone from the drop-down list. Greenwich Mean Time (GMT) is the default.
2. In “Time Display,” you may select the 12- or 24-hour format from the drop-down list. The 24-hour setting is the default.
3. In “Time Format,” you may select either the MM/DD/YY and DD/MM/YY date format from the drop-down list. Month first is the default.
4. Select **Daylight Savings** if you would like your Room Alert 32E time setting to compensate by +1 hour for daylight savings time.
5. In “Time Server IP,” you may leave Room Alert’s default Network Time Protocol (NTP) server IP address, 198.82.1.201, or enter another time server IP address.
6. However, if you’d rather enter your NTP hostname, such as “time.nist.gov,” click **Resolve hostname?**

- When the “DNS Resolver” dialog box opens, enter the hostname of your time server and click Resolve.




Enter your NTP hostname and the device will attempt to resolve the IP address. (e.g. time.nist.gov)

time.nist.gov

Resolving time.nist.gov...

- After the resolver successfully translates the hostname into an IP address, click Insert to put that IP address into the “Time Server IP” field in the Advanced Settings screen.



Resolve was a success!

Resolved IP: 216.171.120.36

Click Insert to put the resolved IP into the setup form.


216.171.120.36

Time Server IP 216.171.120.36 [Resolve hostname?](#)

7. In “Time Server Auto Refresh,” you may select how often Room Alert 32E automatically synchronizes with your time server.
 - You may leave the default, “24 Hours,” or choose another interval, as frequent as 10 minutes, from the drop-down list. You may also disable time synchronization by selecting Disabled from the drop-down list.
 - You may manually synchronize the time by clicking Update Now. Clicking this button does not affect the “Auto Refresh” interval.
8. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
9. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

Trace Configuration

You may configure your Room Alert 32E for trace output, which is useful for troubleshooting. Trace output shows the communication between your Room Alert 32E and your mail server, as well as other information, such as the current firmware version, IP address, MAC address, and requests to web pages.

A screenshot of a web interface titled "Trace Configuration". It contains two settings: "Enable Tracing" with a checked checkbox, and "Trace Port" with a text input field containing the number "143".

Trace Configuration	
Enable Tracing	<input checked="" type="checkbox"/>
Trace Port	143

To configure trace output:

1. Select **Enable Tracing**.
2. In "Trace Port," you may leave the default port, 143, or enter another port number.
3. Click **Accept Changes** at the bottom of your screen to temporarily save your settings. You may now navigate to another screen; however, if you close the web interface before the next step, you will lose your changes.
4. Click **Save Settings** in the navigation bar to the left of your screen. Your Room Alert 32E will automatically reboot and commit your changes.

You may then use any standard telnet or terminal application to view the trace on the configured port.

Help

Click the **Help** tab to open the Room Alert 32E Help screen, which provides helpful links and contact information for AVTECH support resources.

Room Alert® Advanced Computer Room Environment Monitoring, Alerting & Automatic Corrective Action	
Status	Settings
<div> <div> <div>Room Alert® 32E/W Help</div> <div> <div>Room Alert® 32E/W</div> <div>Firmware vX.X.X</div> <div>Released</div> <div>Click Here To Check For Updates</div> </div> </div> <div> <div>Support Resources</div> <div> User's Guide & Reference Manual Frequently Asked Questions Support Center Downloads </div> </div> <div> <div>Live Chat</div> <div>  </div> </div> <div> <div>Email Support</div> <div>Support@AVTECH.com</div> </div> <div> <div>Phone Support</div> <div> 888.220.6700 (USA & Canada) 401.628.1600 (International) Mon-Fri 9 AM - 5 PM EST </div> </div> </div>	

You may find the version number and release date of the firmware that is installed on your Room Alert 32E on this screen. To check if your Room Alert 32E has the most current version, select **Click Here To Check For Updates**.


TIP



Your Room Alert 32E must be connected to the internet to check for newer firmware versions. Thank you.

About

Click the **About** tab to open the Room Alert 32E About screen, which provides helpful links and contact information for AVTECH sales and support resources.

Room Alert® Advanced Computer Room Environment Monitoring, Alerting & Automatic Corrective Action									
Status	Settings	Help	About						
<div><div>Room Alert® 32E/W About</div><div>Room Alert® 32E/W Firmware vX.X.X Released Click Here To Check For Updates</div><div><table><tr><td>Sales</td><td>Order Online Quote Request Sales@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)</td></tr><tr><td>Support</td><td>Support Home User's Guide & Reference Manual Support@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)</td></tr><tr><td>Website</td><td>AVTECH.com RoomAlert.com EnvironmentMonitor.com</td></tr></table></div><div></div></div>				Sales	Order Online Quote Request Sales@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)	Support	Support Home User's Guide & Reference Manual Support@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)	Website	AVTECH.com RoomAlert.com EnvironmentMonitor.com
Sales	Order Online Quote Request Sales@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)								
Support	Support Home User's Guide & Reference Manual Support@AVTECH.com 888.220.6700 (USA & Canada) 401.628.1600 (International)								
Website	AVTECH.com RoomAlert.com EnvironmentMonitor.com								

You may find the version number and release date of the firmware that is installed on your Room Alert 32E on this screen. To check if your Room Alert 32E has the most current version, click **Click Here To Check For Updates**.



Your Room Alert 32E must be connected to the internet to check for newer firmware versions. Thank you.

Updating & Troubleshooting Your Room Alert 32E

How To Download Firmware & Software Updates From [AVTECH.com](https://www.avtech.com)

Software and firmware updates are available to licensed customers with current “Maintenance Support & Update Service” (MSUS). To download:

1. Go to [AVTECH.com/Downloads](https://www.avtech.com/Downloads), or click Downloads on the menu bar at the top of the screen at [AVTECH.com](https://www.avtech.com).
2. In the Downloads page, enter the following user account information in the “Customer Access” box:
 - Your username, which is the email address we have on file for you
 - Your organization’s password.

**TIP**

Your user account information (download username & password) was emailed to you when you purchased your Room Alert 32E. This can be emailed to you again upon request.

3. Click **Login**.
4. Once you’ve logged in, you’ll see which software and firmware products you are currently enabled for. To download, click the **Download Now** button next to the appropriate product.

How To Update Room Alert 32E’s Firmware

1. Download and save the most recent firmware update for Room Alert 32E from your customer account at [AVTECH.com/Downloads](https://www.avtech.com/Downloads).
2. Open AVTECH’s Device Manager. (If you don’t already have it installed, download it from your customer account.)
3. Select the Room Alert 32E option under the Device Status tab in the navigation bar to the left of your screen.
4. Click the **Update Firmware** link shown under the product name (or the **Update Firmware** button shown at the top of the screen).
5. Then follow the on-screen instructions to complete the update.



IMPORTANT: Be sure that there are no web browsers accessing your Room Alert 32E monitor from anywhere on your network before uploading the firmware as this could cause the firmware update to be incomplete or become corrupted.

How To Discover Room Alert 32E When Your Network Blocks UDP Broadcasts

If your network blocks UDP broadcast packets on port 30718, AVTECH's Device Manager might not be able to automatically locate the Room Alert 32E monitor.

To manually discover your Room Alert 32E, use the Advanced Discovery option in AVTECH's Device Manager Application:

1. Open AVTECH's Device Manager. (If you don't already have it installed, download it from your customer account at AVTECH.com/Downloads.)
2. Navigate to **Advanced Discovery** under the "Device Status" tab in the navigation bar to the left of your screen.
3. In the "Advanced Discovery Options" dialog box, click **Manually Add Device/s Via IP Address**.
4. Enter your Room Alert 32E's IP address or the range of IP addresses assigned to DHCP devices on your network.
5. Click **Begin Scan**, which initiates a TCP scan on port 30718.
6. When the scan is complete, click **Close Window** and your Room Alert 32E should be automatically added to the list of discovered devices.

How To Reset Room Alert 32E To Factory Defaults

You may need to reset your Room Alert 32E to factory defaults if:

- You are moving it to a new location and it must be reconfigured.
- It has been assigned invalid network settings and is therefore inaccessible.
- You have lost your Room Alert 32E's password.

If your Room Alert 32E is accessible on the network, to reset it to factory defaults:

1. Navigate to **Settings** in the web interface.

- Click **Reset Defaults** in the navigation bar to the left.
- Click **Yes** when prompted with “Are you sure you want to Reset Factory Defaults?”

Status	Settings	Help	About
MAC Address: XX-XX-XX-XX-XX-XX		Version: X.X.X	
<ul style="list-style-type: none"> Network SMTP Email SNMP Sensors Alarm Options Security Advanced Save Settings Reset Defaults 	<p>Are you sure you want to Reset Factory Defaults?</p> <p>YES NO</p>		

- Your Room Alert 32E will automatically reboot and attempt to obtain an IP address via DHCP.
- To automatically discover your Room Alert 32E on your network, open AVTECH's Device Manager. (If you don't already have it installed, download it from your customer account at AVTECH.com/Downloads.)

If your Room Alert 32E is not accessible on the network, to reset it to factory defaults:

- With your Room Alert 32E connected to the network and powered on, press and hold the reset button for at least 10 seconds until the left LED over the network jack turns off and then on again.
- Your Room Alert 32E will automatically reboot and attempt to obtain an IP address via DHCP.
- To automatically discover your Room Alert 32E on your network, open AVTECH's Device Manager. (If you don't already have it installed, download it from your customer account at AVTECH.com/Downloads.)

TIP





IMPORTANT: When you reset to factory defaults, you lose all of your previously configured settings, including password security.

Introduction To AVTECH's Device Manager

Device Manager is AVTECH's all-in-one software solution for the discovery, management, monitoring, alerting, logging, graphing, automatic action and more of AVTECH's physical environment monitoring hardware and Axis network cameras.

Manage Unlimited Room Alert & TemPageR Montiors

- ✓ Control all of your Room Alert and TemPageR units from a single web browser interface, accessible from anywhere by internet.
- ✓ Take automatic corrective actions, run scripts and notify unlimited contacts on the device of their choice.
- ✓ Use dashboard widgets to customize your interface and display the information most important to you in real time.
- ✓ Automatically log and graph all of your sensor data for a comprehensive history of environmental conditions. Control the log file size automatically.




Manage Unlimited Network Cameras

- ✓ View all of your Axis camera displays simultaneously—and control who has access!
- ✓ Automatically email Axis camera snapshots in response to alert conditions.
- ✓ Customize your alerts with links to your Axis cameras for one-click access to real-time video.

Expand Device Manager's Functionality With Plugins

- ✓ Send customized reports with advanced statistics according to a schedule or in response to alert conditions. Modify according to each user's needs.
- ✓ Log off, shut down, reboot and execute commands on Windows and Linux / Unix systems across your network.
- ✓ Automatically text or call contacts with alerts using a text, voice or GSM (satellite) modem.



A license for Device Manager is included FREE with the purchase of any AVTECH environment monitor. Download it now from your customer account at AVTECH.com/Downloads.

Order from www.sellcom.com/avtech.html
800-SELLCOM 919-401-0067 support@sellcom.com



AVTECH.com

Protect Your Facility... *Don't Wait Until It's Too Late!*